


Pacific Park Television Distribution System.

Pacific Park has a fibre optic distribution system that delivers both Free to Air television and the full range of Foxtel's programming to two points in each unit.



Free to Air TV

- 1) Connect your flylead to the television outlet on the media converter. (screw in - F Type connection)
- 2) Plug the other end of the flylead into the aerial socket on your television. (generally a Pal connector)
- 3) Ensure the Media converter is plugged in and turned on.
- 4) Retune the TV

FOXTEL

- 1) Contact Foxtel to arrange for a set top box to be connected. The building is listed as 41 Rocklands Road Wollstonecraft. (The installer will provide a cable box as the property is serviced by a TDT system). Subscription charges apply.
- 2) Foxtel rebroadcasts the Sydney free to air channels, however if you would like both Foxtel and FTA a splitter is required to split the signal into two streams (One for Foxtel and one for the TV). The installer may assist if you ask.

Troubleshooting

- * Are you connected to the correct television distribution system? The older system is no longer supported and does not work in all units.
- * Is the media converter plugged in and turned on? From time to time the power connection can come loose from the media converter. Simply push it up to ensure a tight connection.
- * Retuning in many cases only looks for the channels last tuned to. You may need to clear the TV's memory. This can be done by resetting or factory default the TV (generally in the installation menu). If this option is not available you can remove the flylead, do a retune (to find no channels) and reconnect in the flylead before retuning again.

If you still have issues or questions please report them to the building manager for resolution.